

SET SERVICING PRICE LIST

Check gearbox, transfer box and differential oil levels. Topped up if required

	Α	В	С	CHASSIS COMPONENTS			
Check horn	✓	✓	✓	Check for play and roughness is wheel bearings	✓	✓	✓
Check operation of front and rear washers	✓	✓	✓	Check for wear in components with side to side shake	✓	✓	✓
Check for chips or damage to windscreen	✓	✓	✓	Remove road wheels where possible and clean hub	=	✓	✓
Check for internal warning lamps, indicators and gauges	✓	✓	✓	Check for worn suspension arms bushes and bearings	✓	✓	✓
Check condition of pedals, handbrake, gear selection and security of floor mat	✓	✓	✓	Check condition of steering rack/box arms, rods, linkages etc and gaiters	✓	✓	✓
Check operation of rear view mirrors	✓	✓	✓	Check condition of suspension shocks, springs and top mounts	✓	✓	✓
Check condition of seatbelts, buckles and seats	-	✓	✓	Grease suspension joints	-	-	✓
Check operation of windows	-	-	✓	Check anti roll bar link, gaiters and bushes	✓	✓	✓
Inspect for free play in steering	=	✓	✓	Check brake pad thickness	VISUAL		✓
Check operation of internal door handles	-	-	√	Check brake discs for corrosion, scoring, damage and thickness	VISUAL	. ✓	✓
Check condition and lubricate door hinges and locks	=	✓	√	Remove and inspect brake drums, cylinders, shoes and adjusters	-	✓	✓
Check operation of blower motor and air conditioning	-	-	✓	Check for security of brake callipers and carriers	✓	✓	✓
EXTERIOR CHECK				Check security and adjustment of handbrake cables	-	-	✓
Check condition of front and rear wiper blades	1	1	✓	Check for leaks from braking system	✓	✓	✓
Adjust washer jets if required	-	-		Check for corrosion or damage to underside of vehicle	-	✓	✓
Check for projections and security of doors, panels including		,	,	Check correct tyres size fitment and condition including tread	./	√	✓
trim	-	V	✓	depth	•		
Check operation and security of external lights	✓	✓	✓	Adjust tyre pressures to manufacture setting	✓	✓	✓
Check operation of external door locks and handles	-	✓	✓	Reset tyre pressure monitoring system where fitted	✓.	✓.	✓
Check condition and fitment of number plates	✓	✓	✓	Check for damage to road wheels	✓	✓	√
Check condition of fuel cap and seal	=	✓	✓	Refit road wheels and torque to manufacture setting	-	✓	✓
Check security and condition of hub caps or wheel centre caps	✓	✓	✓	POST SERVICE OPERATIONS			
ENGINE AND TRANSMISSION COMPONENTS				Reset inspection and oil service lamp	✓	✓	✓
Apply engine oil flush and fuel system cleaner	=	-	✓	Stamp service book if available	✓	✓	✓
Drain and refill engine oil with correct grade	✓	✓	✓	Carry out road test, check handling, performance and noises	-	✓	✓
Replace Oil filter	✓	✓	✓	After road test quality inspect work	✓	✓	✓
Replace Air filter	-	✓	✓	Clean windscreen	-	✓	✓
Replace external fuel filter	-	-	✓	TOTAL SERVICE POINTS COMPLETED	44	64	79
Replace spark plugs	-	-	✓		• •	•	,,
Replace pollen filter	-	-	✓	PRICE UPTO 2LTR (£)	£105	£155	£225
Engine coolant level	✓	✓	✓	PRICE ABOVE 2 LTR (£)	£120	£185	£285
Engine coolant strength	-	√	√	, ,			
Power steering fluid level	√	√	√				
Check brake fluid level Check clutch fluid level	V	√	√ √	ADD MOT	£50		
Check gearbox and clutch operation	· ·	· /	· /	ADD BRAKE FLUID CHANGE	£25		
Top up screen wash level (with additive on 'C')	./	./	./	ADD COOLANT CHANGE	£35		
Check condition and security of battery. Lubricate terminals	-	√	√	ADD ENGINE FLUSH			
Check alternator charge rate	-	· /	✓	ADD ENGINE FLOSH	£20		
Check security and condition of engine bay trim and fixtures	✓	√	√				
Check for fluid leaks	✓	✓	✓	BRAKE FLUID CHANGE	£50		
Check condition of coolant pressure cap	✓	✓	✓	COOLANT CHANGE	£45		
Check for visual damage of radiator, air conditioning condense and intercooler	r ✓	✓	✓	DIAGNOSTIC (MOBILE)	£40		
Check operation of cooling fan	=	-	✓	DIAGNOSITIC	£30		
Check condition and security of engine bay pipe work and	√	✓	✓	DPF SERVICE – ADDATIVE, REGEN AND OIL CHANGE	£240		
wiring Check condition of auxiliary drive belt	,	✓	√	MAIN DEALER SCHEDULE SERVICING	POA		
Check tension of auxiliary drive belt	-	-	✓				
Visual check of exhaust smoke	-	✓	√	AD-BLUE 10 LTR TOP-UP	£30		
Check condition and fitment of coil packs or HT leads	=	-	√	STANDARD CURRENT LABOUR RATE (PLUS VAT)	£52		
Check condition/fitment of bonnet latch and lubricate	✓	✓	✓				
Check manufacture recommendation of cambelt/chain	_	✓	✓				
replacement Check condition and security of underside pipe work and wirin	σ -	· ✓					
Check condition and security of underside pipe work and wiring Check condition and security of arch liners and under trays	-	y ./	√				
Check condition and security of exhaust system	✓	<i>y</i>	√				
Check condition and fitment of drive shafts, prop shaft and	•	,	-				
gaiters	✓	✓	✓				
Grease prop shaft joints	=	-	✓				
Check gearboy transfer boy and differential oil levels. Tonned							