

## **SET SERVICING PRICE LIST**

		_	_
	Α	В	С
Check horn	✓	✓	✓
Check operation of front and rear washers	✓	✓	✓
Check for chips or damage to windscreen	✓	✓	✓
Check for internal warning lamps, indicators and gauges	✓	✓	✓
Check condition of pedals, handbrake, gear selection and	✓	✓	✓
security of floor mat	•	v	•
Check operation of rear view mirrors	✓	✓	✓
Check condition of seatbelts, buckles and seats	-	✓	✓
Check operation of windows	-	-	✓
Inspect for free play in steering	-	✓	✓
Check operation of internal door handles	-	-	✓
Check condition and lubricate door hinges and locks	-	✓	✓
Check operation of blower motor and air conditioning	-	-	✓
EXTERIOR CHECK			
Check condition of front and rear wiper blades	✓	✓	✓
Adjust washer jets if required	-	-	✓
Check for projections and security of doors, panels including trim	-	✓	✓
Check operation and security of external lights	,	,	,
, ,	✓	<b>√</b>	<b>√</b>
Check operation of external door locks and handles	,	<b>√</b>	<b>√</b>
Check condition and fitment of number plates	✓	✓	✓
Check condition of fuel cap and seal	-	✓	✓
Check security and condition of hub caps or wheel centre caps	✓	✓	✓
ENGINE AND TRANSMISSION COMPONENTS			
Apply engine oil flush and fuel system cleaner			,
Drain and refill engine oil with correct grade	,	,	٧,
Replace Oil filter	<b>√</b>	<b>√</b>	<b>√</b>
•	✓	<b>√</b>	<b>√</b>
Replace Air filter	-	✓	٧,
Replace external fuel filter	-	-	<b>√</b>
Replace spark plugs	-	-	<b>√</b>
Replace pollen filter	-	-	<b>√</b>
Engine coolant level	✓	<b>√</b>	<b>√</b>
Engine coolant strength	-	✓.	√
Power steering fluid level	<b>√</b>	<b>√</b>	√
Check brake fluid level	<b>√</b>	<b>√</b>	✓
Check clutch fluid level	✓	✓	✓
Check gearbox and clutch operation	<b>√</b>	<b>√</b>	<b>√</b>
Top up screen wash level (with additive on 'C')	✓	✓	✓
Check condition and security of battery. Lubricate terminals	-	<b>√</b>	✓.
Check alternator charge rate	-	✓.	✓.
Check security and condition of engine bay trim and fixtures	✓	✓	✓
Check for fluid leaks	✓	✓	✓
Check condition of coolant pressure cap	✓	✓	✓
Check for visual damage of radiator, air conditioning condenser and intercooler	✓	✓	✓
Check operation of cooling fan	_	_	✓
Check condition and security of engine bay pipe work and			•
wiring	✓	✓	✓
Check condition of auxiliary drive belt	✓	✓	✓
Check tension of auxiliary drive belt	_		✓
Visual check of exhaust smoke	_	✓	✓
Check condition and fitment of coil packs or HT leads	_	-	✓
Check condition/fitment of bonnet latch and lubricate	✓	✓	
Check manufacture recommendation of cambelt/chain	•		
replacement	-	✓	✓
Check condition and security of underside pipe work and wiring	-	✓	✓
Check condition and security of arch liners and under trays	-	✓	✓
Check condition and security of exhaust system	✓	✓	✓
Check condition and fitment of drive shafts, prop shaft and	✓	✓	✓
gaiters	٧	٧	٧
Grease prop shaft joints	-	=	✓
Check gearbox, transfer box and differential oil levels. Topped	-	-	✓
up if required			

## CHASSIS COMPONENTS

Check for play and roughness is wheel bearings	✓	✓	✓
Check for wear in components with side to side shake	✓	✓	✓
Remove road wheels where possible and clean hub	=	✓	✓
Check for worn suspension arms bushes and bearings	✓	✓	✓
Check condition of steering rack/box arms, rods, linkages etc and gaiters	✓	✓	✓
Check condition of suspension shocks, springs and top mounts	✓	✓	✓
Grease suspension joints	-	-	✓
Check anti roll bar link, gaiters and bushes	✓	✓	✓
Check brake pad thickness	VISUAL	✓	✓
Check brake discs for corrosion, scoring, damage and thickness	VISUAL	✓	✓
Remove and inspect brake drums, cylinders, shoes and adjusters	Ξ	✓	✓
Check for security of brake callipers and carriers	✓	✓	✓
Check security and adjustment of handbrake cables	-	-	✓
Check for leaks from braking system	✓	✓	✓
Check for corrosion or damage to underside of vehicle	-	✓	✓
Check correct tyres size fitment and condition including tread depth	✓	✓	✓
Adjust tyre pressures to manufacture setting	✓	✓	✓
Reset tyre pressure monitoring system where fitted	✓	✓	✓
Check for damage to road wheels	✓	✓	✓
Refit road wheels and torque to manufacture setting	-	✓	✓
POST SERVICE OPERATIONS			
Reset inspection and oil service lamp	✓	✓	✓
Stamp service book if available	✓	✓	✓
Carry out road test, check handling, performance and noises	-	✓	✓
After road test quality inspect work	✓	✓	✓
Clean windscreen	-	✓	✓
TOTAL SERVICE POINTS COMPLETED	44	64	79